

Pairing Your Bumper Cars

Each bumper car is designed to pair with the **same color remote control**:

- **Green remote** → **Green car**
- **Red remote** → **Red car**

Step-by-Step Pairing:

1. Keep both bumper cars in the **OFF** position.
2. Turn **ON** only one car (e.g., Green Car).
3. Install batteries into the matching controller (e.g., Green Controller). **Press any button** on the controller to check if it has paired with the active car.
4. Repeat the process for the second set.

Example (Troubleshooting):

If you accidentally turn on the **Red Car** while replacing batteries in the **Green Controller**, the Green Controller will pair with the Red Car.

If this happens, please follow these steps to reset:

1. Turn **OFF** both cars.
2. Remove the batteries from the controller.
3. **Re-install** the batteries into the controller.
4. Turn **ON** only the matching car (e.g., Green Car). **Press any button** on the controller to check if it has paired.

Remarks:

Always restart the pairing process **one set at a time**, ensuring only the same color car is powered on during battery installation.

Emparejamiento de sus coches de choque

Cada coche de choque está diseñado para emparejarse con el **control remoto del mismo color**:

- **Control remoto verde** → **Coche verde**
- **Control remoto rojo** → **Coche rojo**

Pasos para el emparejamiento:

1. Mantenga ambos coches de choque en la posición **OFF** (apagado).
2. Encienda (**ON**) solo un coche (p. ej., el coche verde).
3. Instale las pilas en el control correspondiente (p. ej., el control verde). **Presione cualquier botón** del control para comprobar si se ha emparejado con el coche activo.
4. Repita el proceso para el segundo conjunto.

Ejemplo (Resolución de problemas):

Si enciende accidentalmente el **coche rojo** mientras cambia las pilas del **control verde**, el control verde se emparejará con el coche rojo.

Si esto sucede, siga estos pasos para restablecer:

1. Apague (**OFF**) ambos coches.
2. Retire las pilas del control remoto.
3. **Vuelva a instalar** las pilas en el control.
4. Encienda (**ON**) solo el coche correspondiente (p. ej., el coche verde). **Presione cualquier botón** del control para comprobar el emparejamiento.

Notas: Reinicie siempre el proceso de emparejamiento **un conjunto a la vez**, asegurándose de que solo el coche del mismo color esté encendido durante la instalación de las pilas.